
Myers Education Center

Distance Learning Classroom

Touch Panel User Guide

Scope:

This user guide covers only **Distance Learning Applications in a Network Session**. Much of the information in this guide is applicable to other session types, however - **Local, Gateway and Video Conference sessions are not covered in this guide.**

Table of contents

Welcome Screen	2
Session Type	3
Teacher Camera Controls	4
Student Camera Controls	6
Elmo Document Camera Controls	7
Play VCR Controls	8
Computer & Auxiliary Controls	9
Record VCR Controls	10
Utilities Controls	11
Volume Controls	<i>Important Note Regarding Echo</i>
Teacher Camera Presets	13
Student Camera Presets	14

Welcome Screen

The Welcome Screen is the first screen that you will see.

If your touch panel screen is black it is most likely in sleep mode.


Touch the face of the panel and this screen should appear.



Touch the screen again to proceed.

Session Type


For a distance learning session, select **Network Session** by touching that button on the Session Type screen.



You will automatically proceed to the next screen.

Teacher Camera Controls


The Teacher Camera Control screen (shown below) appears as the default screen.



The buttons on the bottom of the screen are similar to a tool bar and appear on most screens selected.

Touch the button for the equipment you want to control or the function you want to perform.

Teacher Camera Controls continued



Preset Controls

Touch one of the numbered **Preset** buttons to move the camera to an established, preset position.

Store

This button is *only* used when establishing or changing presets. *It will erase previously established Presets.*

(For detailed information about establishing or changing **Presets** see the notes and instructions beginning on page 14 of this section.)

Pan/Tilt Controls

Touch the triangles [▲] that point up, down, right, and left, to pan and tilt the Teacher Camera to any desired position.

Zoom Controls

Touch **Tele** to zoom the camera in tighter or **Wide** to zoom the camera out further.

Auto-track Controls


Touch Auto Track **Tight** or Auto Track **Wide** to activate the camera tracking feature. Touch one of the **Numbered Presets** to deactivate the tracking system. [More information about the Auto-track feature is in the Teacher Camera section of this guide.](#)

Utilities will take you to that control screen.

Tool Bar Buttons

All other buttons will take you to screens indicated by the text.

Student Camera Control Screen



Pan / Tilt / Zoom Controls

Operate these controls the same as you would for the Teacher Camera.

Preset Controls

Operate the Preset Controls the same as you would for the Teacher Camera.


Cover Shot is a special Preset that should be adjusted to a camera position that is [just wide enough](#) to allow all of the students to be seen in one shot.

Store is *only* used when establishing or changing presets. [It will erase previously established presets.](#) (For detailed information about establishing or changing camera position presets, see the **Presets** instructions beginning on page 13 of this section.)

Utilities will take you to that control screen.

Elmo


The Elmo Document Camera adjustments are be made at the Elmo.



Record VCR will take you to control screen for the lower of the two VCRs in the equipment rack at the teacher's podium.

Play VCR Control Screen

The Play VCR is the top VCR of the two located in the teacher podium.



- Rewinds the videotape.
- Plays the videotape.
- Fast-forwards the videotape.
- Stops the videotape.
- Pauses the videotape.

VCR Room Volume Control controls the level of volume that you hear and transmit to the receiving classrooms.


Channel is for control of in-room cable TV that may be installed in the future.

Privacy Activated will flash when that feature is activated. See *Utilities page 11*.

Record VCR will take you to controls for the record VCR.

Computer and Auxiliary Controls

When you select the computer or an auxiliary video source (such as a camcorder or DVD player), you will see one of these screens.



Computer – Auxiliary Volume Controls

If you have an auxiliary audio source input into the rack, or if you have the computer selected, you will be able to control the volume from those sources at these screens.


NOTE: If you excessively increase the volume levels it may cause echo or other audio disturbances. (See page 12 for detailed information on volume control.)

If you adjust the output volume controls that are on the individual pieces of equipment (computer, camcorder, DVD, etc.), it will affect both the room volume and the transmitted audio level.

All other adjustments for the computer or auxiliary equipment should be made at the individual equipment.

Record VCR Controls

When you select the **Record VCR** button you will see the screen below.



The Record VCR is the bottom of the two located in the teacher podium.

Site Recording Controls

Touch **Local**, **Site A**, **Site B**, or **Site C** to record the video from that particular site.

Quad Split will record all four sources at once, each image reduced to quarter size.

Recording will continue, even if you leave this screen, until you return to the Record VCR control screen and press **Stop** or your tape reaches the end.

Note: While you may record only one video source at a time, you record all audio from all sites in the cluster onto the tape.


BOCES

**Distance
Learning
Program**

Help Desk 1-888-427-9173

Quality • Access • Support

Utilities




Panel Adjustments allow you to control the brightness and contrast of the touch screen display.

Volume Control Screen will take you to the screen where you can make fine adjustments to the incoming volume from individual sites.

Audio Privacy will turn off or on (depending on its position) all microphones in your room. You will still be able to hear remote sites, but they will not hear you. When activated, "Audio Privacy" will flash on the touch screen.

Volume Control Screen



Remote Sites

The incoming volume of each individual remote site can be adjusted with the controls under the appropriate label, **Site A**, **Site B**, or **Site C**. Adjustments are made with the [▲] and [▼] buttons.

Room this control increase or decrease the overall volume in the room.

Individual student and teacher microphones are automatically set in this room and volumes are reset to the default adjustments (50%) whenever the room is powered down. This is not the case in every school on the DL network. Some schools have manual control of their individual microphone volumes.

IMPORTANT NOTE REGARDING AUDIO ECHO

A common cause of echo is the excessive increase in site audio levels in an attempt to compensate for an individual who is speaking very softly and/or leaning back from their microphone.

The solution is to have the individual speak in a normal tone of voice and sit closer to the microphone.


If the individual is at a remote site that has individual microphone controls, you can request that the remote site increase **only** that microphone level. Please note that any adjustments you make to your volumes in your session may not work well in subsequent sessions.

Camera Presets

Presets allow the convenient and quick choice of regularly used camera views by selecting one of the **Preset** buttons (instead of having to pan, tilt, and zoom in or out to a desired view each time.)

There are two types of camera presets that can be established, Teacher Camera Presets and Student Camera Presets. The procedure is similar in each case.

1. Teacher Camera Presets




Note: **Preset 1** should be set as a fairly close shot of the instructor behind the teacher desk. However, Presets can be set to any camera shot based on your needs.

To establish or change a teacher camera preset:

- A. Select (press) one of the numbered **Preset** buttons.
- B. Pan, tilt, and zoom the camera to the shot that you want by using the triangles and the **Zoom In** and **Zoom Out** buttons.
- C. Press **Store**.
- D. Press that same **Preset** button again.

2. Student Camera Presets



The student camera presets are established so the teacher or the aide can select preset student camera views using the Student Camera Control screen on the touch panel.

To establish or change a student camera preset:

- A. Select a Preset or Cover Shot at the right of the screen. (The Cover Shot should be **just wide enough** to allow all students to be seen in one shot.)
- B. Pan, tilt, and zoom the camera to the shot that you want by using the triangles and the **Zoom In** and **Zoom Out** buttons.
- C. Press **Store**.
- D. Press that same **Preset** button again.